

EINBAUMASSE**RG 50**

		LB 2 000	LB 3 000	LB 4 000	LB 5 000	LB 6 000	LB 7 000	LB 8 000
LH 2 000	SH	530	530	530	530	530	550	550
	AS	235	240	240	250	260	290	310
	LS	200	200	200	200	200	250	250
LH 3 000	SH	550	550	550	550	550	570	590
	AS	240	250	260	260	270	310	310
	LS	200	200	200	200	200	250	250
LH 4 000	SH	620	620	620	620	680	680	700
	AS	240	260	270	270	290	310	310
	LS	200	200	200	200	250	250	250
LH 5 000	SH	640	640	640	640	700	700	710
	AS	250	270	270	290	290	310	310
	LS	200	200	200	200	250	250	250

LB = Lichte Breite, LH = Lichte Höhe, SH = erforderliche Sturzhöhe,
 AS = Platzbedarf Antriebsseite, LS = Platzbedarf Lagerseite